


# Monitor

Documentation for the "Monitor" section.

- Synth messages
- Clear messages
- Expand monitor view
- Shrink monitor view

# Synth messages

The monitor displays events coming from your synthesizer, e.g. :



		Clear						
NOTE ON	NOTE	F 4	VELOCITY	20	14 h	NOTE NUMBER	65	41 h
NOTE OFF	NOTE	F 4	VELOCITY	0	00 h	NOTE NUMBER	65	41 h
MOD	VALUE	17	11 h					
MOD	VALUE	20	14 h					
MOD	VALUE	22	16 h					
MOD	VALUE	23	17 h					
MOD	VALUE	25	19 h					
MOD	VALUE	26	1A h					
MOD	VALUE	28	1C h					


Messages displayed are

- System Exclusive
- Pitchbend
- NRPN
- Channel aftertouch
- Channel mode
- Bank MSB
- Bank LSB
- Program change
- Key aftertouch
- Note on
- Note off
- Control change

# Clear messages

Older incoming messages are removed automatically. However, if you want to delete all messages history you can:

1. Click on **Clear** button at the top of the **Monitor** section.



Messages are cleared immediately. This operation cannot be reverted.

# Expand monitor view

It is possible to expand the monitor view for greater confort. While expanded, the monitor uses the whole main space. Other sections are hidden.

To expand the monitor view:

1. Click on  button

The monitor is now bigger and other sections such as **Manage** and **Backup** are hidden.

# Shrink monitor view

To shrink the monitor view:

1. Click the  button

The view will revert to its original state and hidden sections will be visible again.