Expand monitor view

It is possible to expand the monitor view for greater confort. While expanded, the monitor uses the whole main space. Other sections are hidden.

To expand the monitor view:

1. Click on  button

The monitor is now bigger and other sections such as **Manage** and **Backup** are hidden.

Revision #1
Created 21 January 2023 23:21:22 by TJ
Updated 21 January 2023 23:21:38 by TJ